

USER GUIDE

Firmware Version: 1.2.x Last updated on Oct 1, 2025

PHANTOM PHANTOM ANC PHANTOM EXTREME BASS

SMART FULL-FACE HELMET WITH MESH COMMUNICATION



QUICK REFERENCE

+ : (+) button

⊖ : (–) button

© : Center button (HL) : Headlight button

(ANC): ANC button *Only available on PHANTOM ANC

M : Mesh Intercom button

(TL): Taillight button

| Power off Volume up/down ANC & Ambient mode ANC on/off Ambient mode ANC on/off Ambient mode ANC on/off Ambient mode Ambient mode Ambient mode Ambient mode Ambient mode Ambient mode Ambient mode on/off Ambient mode Ambient mode on/off Ambient mode on/off Ambient mode Ambient mode on/off Ambient mode on/off Ambient mode Ambient mode on/off Ambient mode on/off Ambient mode on/off Ambient mode on/off Ambient mode on/off Ambient mode on/off Ambient mode on/off Ambient mode on/off Ambient mode on/off HL Single tap Press for 5 second Single tap Press for 2 second Press for 2 second Press for 2 second Press for 2 second Press for 3 second Press for 1 second Press for 1 second Track forward/back Press for 3 second Mesh Intercom on/off Mute/unmute mic Channel selection Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom on Wave Intercom on Wave Intercom on Wave Intercom off Wave Intercom off Wave Intercom off Mode Single tap | Туре | Operation | Button | Duration |
|--|--------------------------|-------------------------|----------------------|----------------------|
| Power off Volume up/down ANC & Ambient mode ANC on/off Ambient mode ANC on/off Ambient mode Ambient mode on/off Ambient mode Ambient mode Ambient mode on/off Ambient mode Amc Single tap Press for 1 second Answer phone call Ombient ap Ambient mode Amc Single tap Single tap Single tap Answer phone call Ombient mode Ambient mode Amc Single tap Answer phone Ambient mode Ambient mod | | Power on | © & + | Press for 1 second |
| Note and the process of the process | | Power off | © & + | Single tap |
| Ambient mode Ambient mode Ambient mode Ambient mode Ambient mode on/off Amc Press for 1 second Headlight on/off Taillight on/off Press for 5 second Press for 2 second Press for 1 second Press for 3 second Press for 3 second Track forward/back Press for 3 second Mesh Intercom on/off Mute/unmute mic Channel selection Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom on Wave Intercom on Wave Intercom off | | Volume up/down | ● or ⊝ | Single tap |
| Headlight on/off | Ambient | ANC on/off | ANC | Single tap |
| Taillight on/off Press for 5 second Single tap Press for 2 second Press for 2 second Press for 2 second Press for 3 second Play/Pause music Track forward/back Track for 2 secondor Track for 3 secondor Track for 2 secondor Track for 2 seco | | Ambient mode on/off | ANC | Press for 1 second |
| Taillight on/off Phone pairing Phone pairing Answer phone call End phone call Press for 2 second Press for 3 second Play/Pause music Track forward/back Track forward/back Track forward/back Mesh Intercom on/off Mush Intercom on/off Mute/unmute mic Channel selection Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom on Maye Intercom on Maye Intercom off Mayer Intercom o | LED light | Headlight on/off | HL | Single tap |
| Answer phone call End phone call End phone call Cook Press for 2 second Press for 2 second Press for 3 second Press for 3 second Press for 1 second Press for 3 second Press for 1 se | | Taillight on/off | TL | Single tap |
| Phone End phone call Reject phone call Speed dial Play/Pause music Track forward/back Mesh Intercom Mesh grouping Mesh Reach-Out request Nave Intercom Wave Intercom Fress for 2 second Press for 2 second Press for 3 second Press for 1 second Press for 3 second Press for 3 second Press for 3 second Press for 3 second Press for 1 second Press for 5 second Press for 5 second Press for 5 second Press for 8 second Wave Intercom on Maye Intercom off Wave Intercom off Press for 8 second Single tap Wave Intercom off Single tap | Phone | Phone pairing | © | Press for 5 seconds |
| Phone Reject phone call Speed dial Press for 2 second Play/Pause music Track forward/back Mesh Intercom Intercom Mesh Reach-Out request Reset mesh Wave Intercom off Wave Intercom off Press for 2 second Press for 3 second Press for 1 second Press for 3 second Press for 5 second Press for 5 second Press for 5 second Press for 5 second Press for 8 second Press for 9 secon | | Answer phone call | © | Single tap |
| Speed dial Play/Pause music C Press for 1 second Fress for 1 second Fress for 1 second Fress for 3 second Fress for 1 second Fress for 3 second Fress for 3 second Siri or Google Assistant Mesh Intercom on/off Mute/unmute mic Channel selection Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom on Wave Intercom off Wave Intercom off Press for 3 second Fress for 3 second Double tap Fress for 1 second Triple tap Press for 5 second Press for 5 second Single tap Wave Intercom on Double tap Wave Intercom off Wave Intercom off Single tap | | End phone call | © | Press for 2 seconds |
| Play/Pause music Track forward/back or Press for 1 second Press for 1 second Press for 3 second Mesh Intercom on/off Mute/unmute mic Channel selection Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom on Wave Intercom off Wave Intercom off Press for 1 second Press for 1 second Press for 1 second Press for 1 second Triple tap Press for 5 second Wave Intercom on Double tap Wave Intercom off Wave Intercom off Single tap | | Reject phone call | © | Press for 2 seconds |
| Track forward/back Siri or Google Assistant Mesh Intercom on/off Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom™ Track forward/back or ○ Press for 1 second Single tap Press for 1 second Double tap Press for 5 second Triple tap Wave Intercom on Wave Intercom off Wave Intercom off Single tap Press for 1 second Triple tap Press for 5 second Double tap Single tap Single tap | | Speed dial | • | Press for 3 seconds |
| Mesh Intercom on/off Mesh Intercom on/off Mesh Intercom on/off Mesh Intercom on/off Mute/unmute mic Mesh Intercom | | Play/Pause music | © | Press for 1 second |
| Mesh Intercom on/off Mute/unmute mic Channel selection Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom off Wave Intercom off Mesh Intercom on/off Mute/unmute mic Press for 1 second Double tap Press for 5 second Triple tap Press for 8 second Double tap Wave Intercom on Wave Intercom off Single tap | | Track forward/back | • or - | Press for 1 second |
| Mesh Intercom™ Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom™ Mute/unmute mic Channel selection Double tap Press for 5 second Triple tap Press for 8 second Double tap Wave Intercom on Wave Intercom off Single tap | Siri or Google Assistant | | © | Press for 3 seconds |
| Mesh Intercom™ Channel selection Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom on Wave Intercom off Wave Intercom off Double tap Double tap Press for 5 second Triple tap Press for 8 second Double tap Single tap | | Mesh Intercom on/off | M | Single tap |
| Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom off Wave Intercom off Mesh grouping Press for 5 second Triple tap Press for 8 second Double tap Single tap | | Mute/unmute mic | M | Press for 1 second |
| Mesh grouping Mesh Reach-Out request Reset mesh Wave Intercom off | | Channel selection | M | Double tap |
| Reset mesh Wave Intercom off | | Mesh grouping | M | Press for 5 seconds |
| Wave Intercom on | | Mesh Reach-Out request | M | Triple tap |
| Wave Intercom off | | Reset mesh | M | Press for 8 seconds |
| Intercom™ Wave Intercom off Single tap | | Wave Intercom on | M | Double tap |
| | | Wave Intercom off | M | Single tap |
| Switch to Mesh Intercom (C) Single tap | | Switch to Mesh Intercom | © | Single tap |
| Configuration menu © Press for 10 second | Configuration menu | | © | Press for 10 seconds |



BEFORE GETTING STARTED

Sena Motorcycles App

Download the Sena Motorcycles app from the Google Play Store or the App Store.





WAVE Intercom App


Download the WAVE Intercom app from the Google Play Store or the App Store.





For detailed information on the Wave Intercom, please refer to the Wave Intercom User Guide at $\underline{\text{sena.com}}$.

CLICK ANY SECTION TO BEGIN






11 ABOUT THE PHANTOM SERIES

Key Features

- Mesh Intercom 3.0 delivers improved sound quality, a more robust connection, and extended talk time
- Dual version Mesh Mesh 2.0 for backward compatibility
- · Professional studio quality sound with integrated speakers
- Al-based noise cancellation
- Enhanced voice command
- · Front headlight
- · Rear running and brake taillight
- Bluetooth version 5.3
- Over-the-Air (OTA) firmware update
- Active Noise Control & Ambient mode (Only on PHANTOM ANC)
- Enhanced bass sound with upgraded cheek pads (Only on PHANTOM EXTREME BASS)





- 3 Taillight button
- ⑤ Status LED
- 7 Center button
- Reset pinhole
- 11 Charging LED
- [®] Headlight

- 4 Mesh Intercom button
- ⑥ (−) button
- (+) button
- 10 USB-C charging port
- 12 Taillight

^{*}Only available on PHANTOM ANC



Package Contents








Microphone sponges



USB-C charging cable







Removal



Installation






02 BASIC OPERATION

| 1 x | Tap Tap the button the specified number of times |
|------------|---|
| (1s.) | Press and Hold Press and hold the button for the specified amount of time |
| (j) " " | Voice Prompt |
| (II II | Voice Command |
| | LED |

Charging




It takes 2.5 hours to fully charge.


- The PHANTOM helmets feature fast charging, delivering 7 hours of Mesh Intercom with just a 20-minute charge.
- Safe power mode provides continuous power without battery charging to ensure safe, uninterrupted use on the road.
- Any third-party USB charger can be used, as long as it is approved by the FCC, CE, IC, or other locally recognized regulatory agencies.
- Using a non-approved charger may cause fire, explosion, leakage, and other hazards, potentially reducing the battery's lifespan or performance.



Power On








- The PHANTOM helmets enter sleep mode if they remain motionless for 2 minutes.
- If any motion is detected within 3 hours, they wake up. Otherwise, they power off completely after 3 hours.
- To enable or disable this function, go to Device Settings and toggle Auto On/Off in the Sena Motorcycles app.


Volume





Configuration

Enter Configuration



Sound Demo



• Press the center button to cancel.



3 ANC & AMBIENT MODE

ANC (Active Noise Control)

When ANC is activated, the helmet detects external sounds and generates sound waves that cancel them out, reducing surrounding noise.

ANC On/Off



Ambient Mode

When the ambient mode is activated, it allows you to hear external sounds clearly while wearing the helmet.

Ambient Mode On/Off



 Turning on ANC while the ambient mode is active will disable the ambient mode after ANC is turned off.




04 LED LIGHT




In some regions, local laws and regulations restrict the use of LEDs on helmets. Therefore, ensure you are familiar with and comply with the relevant laws and regulations in the area where you use the helmet.

Headlight On/Off



 The headlight automatically turns off approximately 5 minutes after being turned on.

Taillight On/Off



The taillight can be customized through the Sena Motorcycles app. The brake light activates automatically when braking is detected.




PAIRING WITH BLUETOOTH DEVICES

When using the helmet with other Bluetooth devices for the first time, they need to be paired. The PHANTOM series can pair with multiple devices, including two mobile phones and one GPS. However, it supports only one additional device, alongside a mobile phone, for simultaneous connection.

Phone Pairing

1.



2.



- When you turn on the helmet for the first time or reboot it after a factory reset, it will automatically enter phone pairing mode.
- Press any button to cancel phone pairing on the PHANTOM and the PHANTOM ANC.
- Press the center button to cancel phone pairing on the PHANTOM EXTREME BASS.




Second Mobile Phone Pairing

1.



2.




3.




GPS Pairing

1.



2.



3.





Action Camera Pairing

Pairing the PHANTOM helmets with an action camera allows you to record audio from the Mesh Intercom conversations. You can also use the action camera's voice commands via the headset's microphone.

 For detailed instructions on voice commands, refer to the user guide for your action camera.

Device Pairing


1. Put your action camera in Bluetooth pairing mode.



2.



3.



4. Wait until you hear a voice prompt.



• When paired with an action camera, music is disabled.



105 USING WITH A SMARTPHONE

Making and Answering Calls

Answer a Call



I End a Call




Reject a Call





Siri or Google Assistant

Say "Hey Siri", "Hey Google," or press the center button for 3 seconds to activate Siri or Google Assistant.



Speed Dial

Assign Speed Dial Presets

Speed dial presets can be assigned using the Sena Motorcycles app.




Use Speed Dial Presets

1. Enter the speed dial menu.




2. Navigate forward or backward through speed dial preset.



- 1 Last number redial
- ② Speed dial $(1\rightarrow 2\rightarrow 3)$
- ③ Cancel

3. Tap the center button to confirm.




Music

Play/Pause Music



■ Track Forward/Backward






07 MESH INTERCOM


The PHANTOM series provides two Mesh Intercom modes:

- Open Mesh[™] for open group intercom conversations.
- Group Mesh[™] for private group intercom conversations.

Open Mesh



Group Mesh





Mesh Version Switch


Switch to Mesh 2.0 for Backward Compatibility

Mesh 3.0 is the latest Mesh Intercom technology, but to communicate with legacy products using Mesh 2.0, please switch to Mesh 2.0 using the Sena Motorcycles app.

Open Mesh

You can freely communicate with virtually unlimited users in each of the 6 available channels. The default Mesh Intercom channel is 1.


Mesh Intercom On/Off






Mute/Unmute Mic

Press the Mesh Intercom button until the voice prompt is heard to mute/unmute the microphone during Mesh Intercom communication.



Channel Selection

- 1. Enter the channel setting. 2. Navigate between channels.



Confirm and save the channel.




- The channel will be automatically saved if no buttons are pressed for 10 seconds on a specific channel.
- The channel will be saved even if the helmet is turned off.




Group Mesh

By using group mesh, a private conversation group can be created for up to 24 participants.

Create a Group Mesh



1. Users (You, A, and B) enter the mesh grouping by pressing the Mesh Intercom button until the voice prompt is heard while staying in the open mesh. They don't need to be on the same open mesh channel to create a group mesh together.



2. When mesh grouping is completed, it automatically switches from open mesh to group mesh.

(3) "Group Mesh"




• If you want to cancel mesh grouping, tap the Mesh Intercom button.



 If the mesh grouping is not successfully completed within 30 seconds, users will hear a voice prompt saying, "Grouping failed"

Join an Existing Group Mesh

When you are in a group mesh, you can invite other users in open mesh to join the group.



You are already in group mesh with A and B, and the other users, C and D, are in open mesh.

1. You and the other users, C and D, enter mesh grouping by pressing the Mesh Intercom button until the voice prompt.





2. When mesh grouping is completed, the other users, C and D, automatically join the group mesh while leaving the open mesh.


্র) "Group Mesh"

New participants (C and D)

 If the mesh grouping is not successfully completed within 30 seconds, the current user (You) will hear a low tone double beep and the new users (C and D) will hear a voice prompt saying, "Grouping failed."

■ Toggle Open/Group Mesh

You can toggle between open mesh and group mesh without resetting the mesh



 If you have never participated in group mesh, you cannot toggle between open mesh and group mesh. You will hear a voice prompt saying, "No group available."




Mesh Reach-Out Request

You (caller) can send a Mesh Reach-Out request to turn on Mesh Intercom to nearby* friends who have it turned off.

- 1. If you want to send or receive a Mesh Reach-Out request, you need to enable it in the Sena Motorcycles app.
- 2. You can send a Mesh Reach-Out request using the Mesh Intercom button or the Sena Motorcycles app.

Caller




3. Friends who receive the Mesh Reach-Out request need to manually turn on their Mesh Intercom.

* Up to 330 ft in open terrain

Reset Mesh

If the helmet resets the mesh while in open mesh or group mesh, it will automatically return to open mesh, channel 1.






08 WAVE INTERCOM

Wave Intercom enables open communication using cellular data. For detailed information, please refer to the Wave Intercom User Guide on sena.com.

Wave Intercom On/Off

Open the WAVE Intercom app, then double-tap the Mesh Intercom button to join Wave Intercom.

• You must open the app before starting Wave Intercom.




When you start Wave Intercom, you will automatically connect with users in the Wave Zone. The Wave Zone covers a 1-mile radius in North America and a 1.6-km radius in Europe.

To end Wave Intercom, single-tap the Mesh Intercom button.



Switch between Wave Intercom and Mesh Intercom

You can easily switch between Mesh Intercom and Wave Intercom with a single tap on the center button.



9 AUDIO MULTITASKING

Audio multitasking on the PHANTOM series allows you to listen to music and GPS turn-by-turn instructions while having a Mesh Intercom conversation.

For more details, go to Device Settings on the Sena Motorcycles app to configure the settings.

Background Volume

Background audio, such as music playback, will automatically lower in volume during an active intercom conversation. You can adjust the volume reduction percentage in the app under 'Background Volume'.



10 VOICE COMMAND

The PHANTOM series offers multi-language voice commands in eight different languages, which can be easily set through the Sena Motorcycles app. A complete list of available voice commands is also provided in the Sena Motorcycles app.

To activate voice commands, simply say, "Hey Sena."



Voice Command List

- "Answer"
- "Ignore"
- "Hey Sena, Check Battery"
- "Hey Sena, Volume Up"
- "Hey Sena, Volume Down"
- "Hey Sena, Phone Pairing"
- "Hey Sena, Redial Number"
- "Hey Sena, End Call"
- "Hey Sena, Play Music"
- "Hev Sena. Stop Music"
- "Hey Sena, Previous Track"
- "Hey Sena, Next Track"
- "Hey Sena, Mesh Intercom On"
- "Hey Sena, Mesh Intercom Off"
- "Hey Sena, Wave Intercom On"
- "Hey Sena, Wave Intercom Off"



11 FIRMWARE UPDATE


Over-the-Air (OTA) Update

You can update the firmware via Over-the-Air (OTA) directly from the settings in the Sena Motorcycles app.

12 TROUBLESHOOTING

Factory Reset

To restore the helmet to its factory default settings, simply use the factory reset feature.






Fault Reset

If the helmet is on but not responding, you can perform a fault reset to restore normal functionality.

Use a clip to press the reset pinhole next to the USB-C charging port.

All settings will remain unchanged.





Copyright 2025 Sena Technologies, Inc. All rights reserved.

© 1998–2025 Sena Technologies, Inc. All rights reserved.

Sena Technologies, Inc. reserves the right to make any changes and improvements to its product without providing prior notice.

Sena™ is a trademark of Sena Technologies, Inc. or its subsidiaries in the USA and other countries.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sena is under license.

Sena Technologies, Inc. 152 Technology Drive, Irvine, CA 92618