




SRL-EXT

MOTORCYCLE MESH & BLUETOOTH®
COMMUNICATION SYSTEM FOR SHOEI HELMETS

SOUND BY


harman/kardon

QUICK START GUIDE


ENGLISH / 1.0.0

Downloadable Sena Software

Download the **SENA MOTORCYCLES App** on **Google Play Store** or **App Store**.




Download the following items at **sena.com**.



Follow us on Facebook, YouTube, Twitter and Instagram to check the latest information and helpful tips.

SENA SENA Technologies, Inc.
Customer Support: sena.com
















Product Details



Installation


The **SHOEI's RF-1400 Helmet** is compatible with the **SRL-EXT**.
The model name of the **RF-1400 Helmet** varies depending on the region.

- **RF1400(US), NXR 2(EU), Z-8(JP)**
- For more information about installation, refer to the User's Guide.



Mesh Intercom Antenna




Pull the **Mesh Intercom Antenna** inwards slightly to unfold it.




Icon Legend

- TAP 1x**: Tap button the specified number of times
- HOLD 10s**: Press and Hold button for the specified amount of time
- "Hello"**: Audible prompt




Basic Operations



Checking the Battery Level






Phone Pairing



• For more information on phone pairing, refer to the User's Guide.

Using the Phone



Siri and Google Assistant

Activate the **Siri** or **Google Assistant** Installed on Your Phone



Music Control

Mesh Intercom™




Open Mesh™: communication within the same channel.
Group Mesh™: communication within the same private group.

• For more information on **Mesh Intercom**, refer to the User's Guide.

Note: When **Mesh Intercom** is on, the **SRL-EXT** will automatically connect to nearby **SRL-EXT** users and the headset will be in **Open Mesh** (default: channel 1) initially.

Open Mesh

Channel Setting (Default: channel 1) in Open Mesh









Note: You can use the **SENA MOTORCYCLES App** to change the channel.

Group Mesh

Group Mesh is a closed group intercom function that allows users to join, leave, or rejoin a group intercom conversation without pairing each headset.


1) Creating a Group Mesh

Creating a **Group Mesh** requires **two or more Open Mesh** users.




Enable/Disable Mic (Default: Enable)

Users can enable/disable the microphone when communicating in a **Mesh Intercom**.




Reset Mesh

If the headset is in an **Open Mesh** or **Group Mesh** resets the **Mesh**, it will automatically return to **Open Mesh** (default: channel 1).



Bluetooth Intercom

Up to three other people can be paired with the headset for Bluetooth intercom conversations.



Intercom Pairing


There are two ways to pair the headset.

Using the Smart Intercom Pairing (SIP)

SIP allows you to quickly pair with your friends for intercom communication by scanning the QR code on the **SENA MOTORCYCLES App** without remembering the button operation.

1. Pair the mobile phone with the headset.
2. Open the **SENA MOTORCYCLES App** and tap **[Smart Intercom Pairing Menu]**.
3. Scan the **QR code** displayed on your friend (B)'s mobile phone.




• Your friend (B) can display the QR code on the mobile phone by tapping **[QR code]** on the **SENA MOTORCYCLES App**.



4. Tap **Save** and check that your friend (B) is paired with you (A) correctly.
5. Tap **Scan** (C) and repeat steps 3-4 to pair with **Intercom Friends** (C) and (D).



Note: The **Smart Intercom Pairing (SIP)** is not compatible with Sena products that use **Bluetooth 3.0** or **below**.

Using the Button






Last-Come, First-Served

If the headset has multiple paired headsets for intercom conversations, the last paired headset is set as the **First Intercom Friend**.






Two-way Intercom

Start/End Conversation with the First Intercom Friend D





FM Radio



Note: You can also save the current station from the **SENA MOTORCYCLES App**.


Configuration Menu

Accessing the Configuration Menu





Troubleshooting

Fault Reset



Note: **Fault Reset** will not restore the headset to factory default settings.

Factory Reset



Quick Reference

TYPE	OPERATION	BUTTON COMMANDS
Basic Operations	Power on / Power off	[Power] (HOLD 1s)
	Volume up / Volume down	[Volume Up] (TAP 1x) or [Volume Down] (TAP 1x)

Mobile Phone	Answer phone call	[Answer] (TAP 1x)
	End phone call	[End Call] (HOLD 2s)
	Reject phone call	[Reject] (HOLD 2s)

Siri and Google Assistant	Activate the Siri or Google Assistant	[Voice Command] (HOLD 3s)
---------------------------	---------------------------------------	---------------------------

Mesh Intercom™	Mesh Intercom on/off	[Mesh Intercom] (TAP 1x)
	Channel setting	[Channel] (TAP 2x)
	Mesh Grouping	[Mesh Grouping] (HOLD 5s)
	Reset Mesh	[Reset Mesh] (HOLD 8s)
	Enable/Disable Mic	[Mic] (HOLD 1s)

Intercom	Intercom pairing	[Intercom Pairing] (HOLD 5s)
	Start/End intercom	[Intercom] (TAP 1x)

Music	Play/Pause music	[Play/Pause] (HOLD 1s)
	Track forward	[Track Forward] (HOLD 1s)
	Track backward	[Track Backward] (HOLD 1s)

FM Radio	FM radio on/off	[FM Radio] (HOLD 1s)
	Select preset	[Preset] (HOLD 1s)
	Seek forward/backward	[Seek Forward/Backward] (TAP 2x)
	Scan up FM band/stop scanning	[Scan Up] (HOLD 1s)